



Assembly instructions

Custom
Clip-on

Adjust the sun glasses:

- + 1 mm extra for rimless frames
- + 2 mm extra for metallic frames
- + 3 mm extra for plastic frames

Mark the fixing points:

Place the frame on the assembly chart. Mark the upper and the lower fixing points. Copy these markings onto the sunglasses.

Fix the spring bar and the lower clip hooks. Clench everything tight with nylon-jaw pliers (Ofar reference M84) with a plier.

Your  **IS READY!**

Phone: +31 (0)320 24 71 04 - www.ofar.nl

Ofar
OPTICAL WHOLESALE

